RadioShack®

14-109

Desktop Cassette Recorder

*Thank you for purchasing your Desktop Cassette Recorder from **RadioShack**. You can make recordings using the built-in microphone or an external microphone, or from an external audio source, such as radio, tape deck, or CD player.*

Recording

1. Prepare the source:
   - **Built-in microphone** – Place the recorder within 2 to 3 feet of the sound source.
   - **External microphone** – Insert the microphone plug into the **MIC** jack. If the microphone has a remote control plug, connect it to the **REM** jack.
   - **Audio source** – Connect the audio source to the **AUX** jack using a mono patch cord and set the audio source's volume to the desired level.
2. Press **STOP**/**EJECT** to load a blank tape.
3. Press **RECORD**. Both **PLAY** and **RECORD** lock down and recording begins.

NOTES

- *Do not force down* **RECORD** *if the tape's erase-protection tabs have been removed, or you will damage the recorder.*
- *The recorder automatically sets the recording level. The* **VOLUME** *setting does not control the recording volume.*

4. Press **STOP**/**EJECT** to stop recording. Recording stops automatically when the tape ends.

Playing a Cassette

Load the cassette with the side to play facing out, and press **PLAY**. The tape will automatically stop when it reaches the end, or you can press **STOP**/**EJECT**.

If the playback sounds distorted clean the recorder with a cassette deck cleaning kit.

Erasing Recordings

Insert the erasing plug into the **MIC** jack and press **RECORD**. Make sure the cassette's erase-protection tabs are in place when you use the erasing plug.

listening safely

To protect your hearing, follow these earphone guidelines:

- Set the recorder to the lowest volume before you turn it on, then adjust the volume to a comfortable level.
- Do not listen at extremely high volume levels. Extended high-volume listening can lead to permanent hearing loss.
- After you set the volume, do not increase it. Over time, your ears adapt to the volume level, so a volume level that does not cause discomfort might still damage your hearing.

Traffic Safety

Do not wear earphones or headphones while operating a motor vehicle or riding a bicycle. This can create a traffic hazard and could be illegal in some areas.

Even though some earphones or headphones let you hear outside sounds, they still can present a traffic hazard.

specifications

Tape System	2-Track Monophonic Cassette
Tape Speed	4.75 cm/sec
Wow and Flutter (UNWTD/ WTD)	<0.45% / 0.25%
S/N Ratio	45 dB
Recording System	Magnetic Erase, AC Bias
Power Requirements	Four C Batteries, or AC Adatper
Dimensions (HWD)	9.5 × 5.6 × 1.8 inches (240×142×46 mm)

Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.

what's included

- **Desktop Cassette Recorder**
- **Erasing Plug**
- **User's Guide**
- **AC Adapter**
- **Earphones**

limited 90-day warranty

This product is warranted by ***RadioShack*** against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from ***RadioShack*** company-owned stores and authorized ***RadioShack*** franchisees and dealers. For complete warranty details and exclusions, check with your local ***RadioShack*** store.

RadioShack Customer Relations
300 RadioShack Circle, Fort Worth, TX 76102 04/04

powering your recorder

Batteries

Open the battery compartment and install four C batteries (not included) matching the polarity symbols (+/-).

Battery Notes:

- *Dispose of old batteries promptly and properly. Do not burn or bury batteries.*
- *Use only fresh batteries of the required size and recommended type.*
- *If you do not plan to use your recorder for a month or more, remove the batteries. Batteries can leak chemicals that can damage electronic parts.*

AC Power

Connect the recorder's **DC 6V** jack to a standard AC outlet using the supplied AC adapter. Always connect the adapter to the recorder first. Unplug the adapter from the outlet before unplugging it from the recorder.

To avoid injury, do not connect the provided power adapter to a ceiling outlet.

NOTE

The power source must supply 6V DC and deliver at least 400mA. Its center tip must be set to positive and its plug must fit the **DC 6V** *jack. Using an adapter that does not meet these specifications could damage the recorder or adapter.*

carrying handle

Slide out the handle out to carry the recorder.

Please read this user's guide before installing, setting up, and using your new cassette recorder.
www.radioshack.com

©2007. ***RadioShack*** Corporation.
All rights reserved. ***RadioShack*** and RadioShack.com are trademarks used by ***RadioShack*** Corporation.

14-109
03A07
Printed in China